

Instructions for Re-cementation of a Temporary Crown

1. Remove as much of the remaining cement from the inside of temporary using the enclosed disposable spatula.
2. Try the temporary restoration in for accurate placement prior to cement placement to insure a proper fit.
3. Dry out the temporary restoration and the prepared tooth with a gauze 2x2, or a cotton roll can also be used.
4. Once prepared tooth structure is dry place a cotton roll and bite down to keep area dry while mixing cement.
5. Cut along dotted line with scissors and dispense contents of package onto a mixing pad or disposable, flat surface.
6. Thoroughly mix the pastes for approximately $\frac{1}{2}$ minute.
7. Spread a thin layer covering the internal surfaces of the temporary.
8. Place temporary onto the prepared tooth.
9. Place cotton roll and bite with firm pressure for approximately 2 minutes.
10. Remove excess cement with the enclosed disposable spatula.